



CHANGING THE WAY YOU GET THERE

90 Bridge Street, Westbrook, Maine 04092



Carrier Installation Instructions



Step One: Loosely Attach Jawz to Carrier – Insert one bolt with washer through Jawz and thread two turns into carrier. The Jawz should be hanging loosely from the carrier after this step.



Step Two: Place Carriers On Cross Rails – Place the carrier on the cross rail with the Jawz hanging under the rail. Confirm the bottom cutout of the carrier is aligned with the rail (square, round or factory oval). Continue to hold the carrier in place and have the second bolt with washer ready for insertion.

DO NOT PLACE THE CARRIERS ON THE OUTSIDE OF THE CROSS RAIL TOWER



CHANGING THE WAY YOU GET THERE

90 Bridge Street, Westbrook, Maine 04092



Step Three: Hand Tighten the Bolts – Insert second bolt with washer through Jawz and thread two turns into carrier. Force the Jawz up until it contacts with the underside of the cross rail. Hand tighten both bolts. If a wrench is required, tighten only enough to hold the carrier in place.



Step Four: Confirm Front and Back Carriers are Aligned. Tighten Bolts – After adjustment for final alignment, tighten bolts with a ½” wrench. Tighten evenly so that both bolts have the same insertion. Note: Some factory oval rails are not a true oval and this can create a slight angle to the Jawz. This is acceptable. Note: Tighten Bolts until firm – Do not over tighten.

DO NOT INSTALL THE CARRIERS IF THE BOLTS DO NOT THREAD AT LEAST 6 FULL TURNS. ORDER THE MPG323 OPTIONAL BOLT KIT AVAILABLE AT YOUR DEALER.

MALONE, 90 BRIDGE STREET, WESTBROOK, ME. 04092 TELE: 207-591-6083
Website: maloneautoracks.com E-Mail: info@maloneautoracks.com