

SAFARI & URBAN RACK APPLICATION GUIDE

VEHICLE	YEAR	SAFARI RACK PART # ¹	RACK SIZE	CROSSBAR	FLOOR KIT PART # ⁵	ADAPTER ²
ACURA						
MDX	2001-2006	S4560	45" x 60"	48"	1112	R5300/CH100
MDX	2007-2008	S5060	45" x 60"	48"	1112	1101
MDX	2009	S5060	50" x 60"	53"	1112	R5300/CH100
RDX	2007	S4050	40" x 50"	43"	1109	R3600/CH100
RDX	2008-2009	S4550	45" x 50"	48"	1110	1101
SLX	1996-2006	S5060	50" x 60"	53"	1112	TR100
AUDI						
A3	2006-2008	S4050	40" x 50"	43"	1109	R3600/CH100
A4 (Wagon)/ AVANT	1998-2009	S4050	40" x 50"	43"	1109	1101
A6 (Wagon)	1995-2009	S4550	45" x 50"	48"	1110	1101
ALL ROAD	2001-2005	S4560	45" x 60"	48"	1112	1101
Q7	2006-2009	S4560	45" x 60"	48"	1112	R5300/CH100
BMW						
3- Series (Wagon)	2000-2009	S4050	40" x 50"	43"	1109	1101
5- Series (Wagon)	1992-2009	S4550	45" x 50"	48"	1110	1101
X3	2004-2009	S4550	45" x 50"	48"	1110	1101
X5	2000-2009	S4560	45" x 60"	48"	1112	1101
BUICK						
ENCLAVE	2008-2009	S4560	45" x 60"	48"	1112	ER100
RENDEZVOUS	2002-2007	S4560	45" x 60"	48"	1112	CH100
RAINER	2003-2006	S4550	45" x 50"	48"	1110	CH100
RAINER	2007	S4550	45" x 50"	48"	1110	1101
TERRAZA	2005-2007	S4560	45" x 60"	48"	1112	1101
CADILLAC						
ESCALADE	1999-2009	S5072 ⁴	50" x 72"	53"	1113	ER100
ESCALADE ESV	2003-2009	S5084 ⁴	50" x 84"	53"	1114	ER100
ESCALADE EXT	2002-2008	S5060	50" x 60"	53"	1112	ER100
SRX	2004-2009	S4550	45" x 50"	48"	1110	1101
CHEVROLET						
ASTRO	1986-2005	S4560	45" x 60"	48"	1112	1101
AVALANCHE	2002-2006	S5060	50" x 60"	53"	1112	R5300/CH100
AVALANCHE	2007-2009	S5060	50" x 60"	53"	1112	1101
BLAZER 2 DR	1986-2005	S5050	50" x 50"	53"	1110	1101
BLAZER S10 2 DR	1995-2005	S4550	45" x 50"	48"	1110	1101

1 -All Safari Rack sizes apply to Urban Rack and Urban Rack Black. For part number just replace the "S" with a "U" or "UB" (S5060=U5060=UB5060).

2 -If vehicle is not equipped with a factory roof rack, after-market roof rack, or rain gutters, then roof rails are available.
 R3600 (to be used with 50" long Safari Rack)..... 36" mount roof rails
 R5300 (to be used with 60" long Safari Rack)..... 53" mount roof rails
 R6200 (to be used with 72", 84" long Safari Rack)..... 62" mount roof rails

3 -If using an existing Yakima or Thule rack use our special adapters to attach Safari Rack to their crossbars.
 Yakima Adapter- Y400 Thule Adapter- T400

4 -When ordering racks larger than 50" x 60" extra adapters are needed:
 S5072- 2 sets (8 adapter pieces) S5084- 2 sets (8 adapter pieces)
 S6572- 2 sets (8 adapter pieces) S65100- 2.5 sets (10 adapter pieces)
 S8072- 2 sets (8 adapter pieces) S80100- 2.5 sets (10 adapter pieces)

5 - Floor kits add extra floor slats to existing Safari Racks to solidify the floor of the rack.

6 - All full size vans need longer crossbars; please mark part number with a "v" at the end (S5060v).

SAFARI & URBAN RACK APPLICATION GUIDE

VEHICLE	YEAR	SAFARI RACK PART # ¹	RACK SIZE	CROSSBAR	FLOOR KIT PART # ⁵	ADAPTER ²
---------	------	---------------------------------	-----------	----------	-------------------------------	----------------------

CHEVROLET continued

BLAZER S10 4 DR	1991-2004	S4560	45" x 60"	48"	1112	1101
COLORADO	2004-2009	S4550	45" x 50"	48"	1110	R3600/CH100
EQUINOX	2005-2006	S4550	45" x 50"	48"	1110	ER100
EQUINOX	2007-2008	S4550	45" x 50"	48"	1110	R3600/CH100
S10 PICKUP	1985-2004	S4050	40" x 50"	43"	1109	R3600/CH100
SILVERADO	1999-2009	S5050	50" x 50"	53"	1110	R3600/CH100
SUBURBAN	1986-2009	S5084 ⁴	50" x 84"	53"	1114	1101
TAHOE 2 DR	1995-1999	S5060	50" x 60"	53"	1112	1101
TAHOE 4 DR	1995-2009	S5072 ⁴	50" x 72"	53"	1113	1101
TAHOE- Z71	2001-2006	S5072 ⁴	50" x 72"	53"	1113	ER100
TRACKER	1998-2004	S4550	45" x 50"	48"	1110	1101
TRAILBLAZER	1999-2009	S4560	45" x 60"	48"	1112	CH100
TRAILBLAZER EXT	2002-2008	S4560	45" x 60"	48"	1112	CH100
TRAVERSE	2009	S5060	50" X 60"	53"	1112	R5300/CH100
VAN (FULL SIZE) ⁶	1986-2009	S5072v ⁴	50" x 72"	60"	1113	GM100
VENTURE	1997-2005	S4560	45" x 60"	48"	1112	1101
UPLANDER	2005-2008	S4560	45" x 60"	48"	1112	1101

CHRYSLER

ASPEN	2006-2009	S5072 ⁴	50" x 72"	53"	1113	1101
PACIFICA	2004-2007	S4550	45" x 50"	48"	1110	R3600/CH100
TOWN & COUNTRY	1990-2007	S4560	45" x 60"	48"	1112	CH100
TOWN & COUNTRY	2008-2009	S4560	45" x 60"	48"	1112	1101
VOYAGER	2000-2003	S4560	45" x 60"	48"	1112	1101

DODGE

CARAVAN	1986-2007	S5060	50" x 60"	53"	1112	1101
GRAND CARAVAN	2007-2009	S5072 ⁴	50" x 72"	53"	1113	1101
DAKOTA	1987-2009	S4550	45" x 50"	48"	1110	R3600/CH100
DURANGO	1998-2002	S5072 ⁴	50" x 72"	53"	1113	DU100
DURANGO	2004-2009	S5072 ⁴	50" x 72"	53"	1113	1101
JOURNEY	2009	S4550	45" x 50"	48"	1110	1101
MAGNUM	2005-2008	S4550	45" x 50"	48"	1110	1101
NITRO	2007-2009	S4550	45" x 50"	48"	1110	R3600/CH100
RAM PICKUP	1986-2009	S5050	50" x 50"	53"	1110	R3600/CH100
RAM VAN ⁶	1971-2009	S5072v ⁴	50" x 72"	60"	1113	GM100

- 1 -All Safari Rack sizes apply to Urban Rack and Urban Rack Black. For part number just replace the "S" with a "U" or "UB" (S5060=U5060=UB5060).
- 2 -If vehicle is not equipped with a factory roof rack, after-market roof rack, or rain gutters, then roof rails are available.
- | | | |
|-------|--|----------------------|
| R3600 | (to be used with 50" long Safari Rack)..... | 36" mount roof rails |
| R5300 | (to be used with 60" long Safari Rack)..... | 53" mount roof rails |
| R6200 | (to be used with 72", 84" long Safari Rack)..... | 62" mount roof rails |
- 3 -If using an existing Yakima or Thule rack use our special adapters to attach Safari Rack to their crossbars.
- | | |
|----------------------|---------------------|
| Yakima Adapter- Y400 | Thule Adapter- T400 |
|----------------------|---------------------|
- 4 -When ordering racks larger then 50" x 60" extra adapters are needed:
- | | |
|----------------------------------|--------------------------------------|
| S5072- 2 sets (8 adapter pieces) | S5084- 2 sets (8 adapter pieces) |
| S6572- 2 sets (8 adapter pieces) | S65100- 2.5 sets (10 adapter pieces) |
| S8072- 2 sets (8 adapter pieces) | S80100- 2.5 sets (10 adapter pieces) |
- 5 - Floor kits add extra floor slats to existing Safari Racks to solidify the floor of the rack.
- 6 - All full size vans need longer crossbars; please mark part number with a "v" at the end (S5060v).

SAFARI & URBAN RACK APPLICATION GUIDE

VEHICLE	YEAR	SAFARI RACK PART # ¹	RACK SIZE	CROSSBAR	FLOOR KIT PART # ⁵	ADAPTER ²
---------	------	---------------------------------	-----------	----------	-------------------------------	----------------------

FORD						
AEROSTAR	1986-1997	S4560	45" x 60"	48"	1112	CH100
BRONCO	1980-1996	S5050	50" x 50"	53"	1110	CH100/R3600
ESCAPE	2001-2007	S4050	40" x 50"	43"	1109	CH100
ESCAPE	2008-2009	S4050	40" x 50"	43"	1109	1101
EXCURSION	2000-2006	S5084 ⁴	50" x 84"	53"	1114	CH100
EXPEDITION	1997-2005	S5072 ⁴	50" x 72"	53"	1113	CH100
EXPEDITION	2006	S5072 ⁴	50" x 72"	53"	1113	1101
EXPEDITION	2007-2009	S5072 ⁴	50" x 72"	53"	1113	ER100
EXPLORER	1991- 2001	S4560	45" x 60"	48"	1112	CH100
EXPLORER	2002-2005	S5060	50" x 60"	53"	1112	1101
EXPLORER	2006-2009	S4560	45" x 60"	48"	1112	ER100
EXPLORER SPORT	1991- 2000	S4550	45" x 50"	48"	1110	CH100
EXPLORER SPORT	2001-2005	S5050	50" x 50"	53"	1110	1101
F-SERIES PICKUP	1986-2009	S5050	50" x 50"	53"	1110	R3600/CH100
FLEX	2009	S4560	45" x 60"	48"	1112	R5300/CH100
FREESTAR	2004-2006	S4560	45" x 60"	48"	1112	1101
FREESTYLE	2005-2007	S4560	45" x 60"	48"	1112	1101
FOCUS WAGON	2000-2009	S4050	40" x 50"	43"	1109	1101
RANGER	1982-2009	S4050	40" x 50"	43"	1109	R3600/CH100
SPORT TRAC	2001-2009	S5050	50" x 50"	53"	1110	1101
VAN (FULL SIZE)	1986-2009	S5072v ⁴	50" x 72"	60"	1113	GM100
WINDSTAR	1995-2003	S4560	45" x 60"	48"	1112	CH100

GEO						
TRACKER	1989-1997	S4050	40" x 50"	43"	1109	1101

GMC						
ACADIA	2007	S4560	45" x 60"	48"	1112	1101
ACADIA	2008-2009	S4560	45" x 60"	48"	1112	ER100
CANYON	2004-2009	S4550	45" x 50"	48"	1110	R3600/CH100
DENALI	1999-2000	S5072 ⁴	50" x 72"	53"	1113	ER100
DENALI	2001-2006	S5072 ⁴	50" x 72"	53"	1113	1101
DENALI	2007-2009	S5072 ⁴	50" x 72"	53"	1113	ER100
DENALI XL	2001-2006	S5084 ⁴	50" x 84"	53"	1114	1101
DENALI XL	2007-2009	S5084 ⁴	50" x 84"	53"	1114	ER100
ENVOY	1998-2009	S4560	45" x 60"	48"	1112	CH100

- 1 -All Safari Rack sizes apply to Urban Rack and Urban Rack Black. For part number just replace the "S" with a "U" or "UB" (S5060=U5060=UB5060).
- 2 -If vehicle is not equipped with a factory roof rack, after-market roof rack, or rain gutters, then roof rails are available.
- | | | |
|-------|--|----------------------|
| R3600 | (to be used with 50" long Safari Rack)..... | 36" mount roof rails |
| R5300 | (to be used with 60" long Safari Rack)..... | 53" mount roof rails |
| R6200 | (to be used with 72", 84" long Safari Rack)..... | 62" mount roof rails |
- 3 -If using an existing Yakima or Thule rack use our special adapters to attach Safari Rack to their crossbars.
- | | |
|----------------------|---------------------|
| Yakima Adapter- Y400 | Thule Adapter- T400 |
|----------------------|---------------------|
- 4 -When ordering racks larger then 50" x 60" extra adapters are needed:
- | | |
|----------------------------------|--------------------------------------|
| S5072- 2 sets (8 adapter pieces) | S5084- 2 sets (8 adapter pieces) |
| S6572- 2 sets (8 adapter pieces) | S65100- 2.5 sets (10 adapter pieces) |
| S8072- 2 sets (8 adapter pieces) | S80100- 2.5 sets (10 adapter pieces) |
- 5 - Floor kits add extra floor slats to existing Safari Racks to solidify the floor of the rack.
- 6 - All full size vans need longer crossbars; please mark part number with a "v" at the end (S5060v).

SAFARI & URBAN RACK APPLICATION GUIDE

VEHICLE	YEAR	SAFARI RACK PART # ¹	RACK SIZE	CROSSBAR	FLOOR KIT PART # ⁵	ADAPTER ²
---------	------	---------------------------------	-----------	----------	-------------------------------	----------------------

GMC continued						
ENVOY XL	2002-2008	S4560	45" x 60"	48"	1112	CH100
ENVOY DENALI	2007-2009	S4560	45" x 60"	48"	1112	CH100
JIMMY 2 DR	1985-2001	S4550	45" x 50"	48"	1110	1101
JIMMY 4 DR	1990-2005	S4550	45" x 50"	48"	1110	1101
PICKUP	1986-2008	S4550	45" x 50"	48"	1110	R3600/CH100
SIERRA	2001-2009	S5050	50" x 50"	53"	1110	R3600/CH100
SUBURBAN	1986-2009	S5084 ⁴	50" x 84"	53"	1114	1101
VAN (FULL SIZE) ⁶	1986-2009	S5084v ⁴	50" x 84"	53"	1114	GM100
YUKON 2 DR	1992-1999	S5060	50" x 60"	53"	1112	1101
YUKON 4 DR	1992-2009	S5072 ⁴	50" x 72"	53"	1113	1101
YUKON XL	2000-2009	S5084 ⁴	50" x 84"	53"	1114	1101
HONDA						
CRV	1997- 2002	S4050	40" x 50"	43"	1109	1101
CRV	2003-2009	S4550	45" x 50"	48"	1110	HN100
ELEMENT	2003-2009	S5060	50" x 60"	53"	1112	HN100
ODESSEY	1995-2009	S4550	45" x 50"	48"	1110	1101
PASSPORT	1994-1997	S4550	45" x 50"	48"	1110	J100
PASSPORT	1998-2002	S4550	45" x 50"	48"	1110	1101
PILOT	1998-2009	S4560	45" x 60"	48"	1112	1101
RIDGELINE	2006-2009	S5060	50" x 60"	53"	1112	ER100
HUMMER						
H1	1993-2004	S8072 ⁴	80" x 72"	83"	1117	GM200
H1	1993-2004	S80100 ⁴	80" x 100"	83"	1118	GM200
H2	2003-2009	S6572 ⁴	65" x 72"	68"	1115	CH100
H2	2003-2009	S65100 ⁴	65" x 100"	68"	1116	CH100
H2 SUT	2005-2009	S6572 ⁴	65" x 72"	68"	1115	CH100
H3	2006-2009	S5060	50" x 60"	53"	1112	CH100
HYUNDAI						
ENTOURAGE	2009	S5060	50" x 60"	53"	1112	1101
SANTA FE	2001-2005	S4550	45" x 50"	48"	1110	1101
SANTA FE	2006-2009	S4050	40" x 50"	43"	1109	ER100
TUCSON	2005-2009	S4550	45" x 50"	48"	1110	1101
VERACRUZ	2008-2009	S4550	45" x 50"	48"	1110	1101

1 -All Safari Rack sizes apply to Urban Rack and Urban Rack Black. For part number just replace the "S" with a "U" or "UB" (S5060=U5060=UB5060).

2 -If vehicle is not equipped with a factory roof rack, after-market roof rack, or rain gutters, then roof rails are available.
 R3600 (to be used with 50" long Safari Rack)..... 36" mount roof rails
 R5300 (to be used with 60" long Safari Rack)..... 53" mount roof rails
 R6200 (to be used with 72", 84" long Safari Rack)..... 62" mount roof rails

3 -If using an existing Yakima or Thule rack use our special adapters to attach Safari Rack to their crossbars.
 Yakima Adapter- Y400 Thule Adapter- T400

4 -When ordering racks larger then 50" x 60" extra adapters are needed:
 S5072- 2 sets (8 adapter pieces) S5084- 2 sets (8 adapter pieces)
 S6572- 2 sets (8 adapter pieces) S65100- 2.5 sets (10 adapter pieces)
 S8072- 2 sets (8 adapter pieces) S80100- 2.5 sets (10 adapter pieces)

5 - Floor kits add extra floor slats to existing Safari Racks to solidify the floor of the rack.

6 - All full size vans need longer crossbars; please mark part number with a "v" at the end (S5060v).

SAFARI & URBAN RACK APPLICATION GUIDE

VEHICLE	YEAR	SAFARI RACK PART # ¹	RACK SIZE	CROSSBAR	FLOOR KIT PART # ⁵	ADAPTER ²
---------	------	---------------------------------	-----------	----------	-------------------------------	----------------------

INFINITY						
QX4	1997-2003	S4560	45" x 60"	48"	1112	CH100
QX56	2004-2007	S5072 ⁴	50" x 72"	53"	1113	R6200/CH100
QX56	2008-2009	S5072 ⁴	50" x 72"	53"	1113	ER100
FX35/45	2003-2009	S4050	40" x 50"	43"	1109	1101
ISUZU						
ASCENDER	2003-2008	S4560	45" x 60"	48"	1112	CH100
AXIOM	2000-2005	S4550	45" x 50"	48"	1110	R3600/CH100
I-290	2009	S4550	45" x 50"	48"	1110	R3600/CH100
I-370	2009	S4550	45" x 50"	48"	1110	R5300/CH100
RODEO	1991-1997	S4550	45" x 50"	48"	1110	J100
RODEO	1998-2004	S4550	45" x 50"	48"	1110	1101
TROOPER	1991-2002	S5060	50" x 60"	53"	1112	TR100
JEEP						
COMMANDER	2006-2009	S5072 ⁴	50" x 72"	53"	1113	J200
CHEROKEE	1985-1992	S4560	45" x 60"	48"	1112	CH100
CHEROKEE	1993-2001	S4560	45" x 60"	48"	1112	J100
COMPASS	2007-2009	S4550	45" x 50"	48"	1110	R3600/CH100
GRAND CHEROKEE	1993-1998	S4560	45" x 60"	48"	1112	J100
GRAND CHEROKEE	1999-2009	S4560	45" x 60"	48"	1112	1101
PATRIOT	2007-2009	S4550	45" x 50"	48"	1110	1101
WAGONEER	1984-1991	S5072 ⁴	50" x 72"	53"	1113	GM100
LIBERTY	2001-2009	S4550	45" x 50"	48"	1110	1101
JEEP- Wrangler						
WRANGLER-HARD TOP	ALL YEARS	S4550	45" x 50"	48"	1110	R3600/CH100
KIA						
BORREGO	2009	S4550	45" x 50"	48"	1110	ER100
RIO 5	2007	S4050	40" x 50"	43"	1109	R3600/CH100
RONDO	2007-2008	S4050	40" x 50"	43"	1109	ER100
SEDONA	2002-2008	S4550	45" x 50"	48"	1110	1101
SORENTO	2003-2008	S5050	50" x 50"	53"	1110	1101
SOUL	2009	S4050	40" x 50"	43"	1109	R5300/CH100
SPECTRA WAGON	2006-2008	S4050	40" x 50"	43"	1109	R3600/CH100
SPORTAGE	1995-2000	S4050	40" x 50"	43"	1109	J100
SPORTAGE	2001-2008	S4550	45" x 50"	48"	1110	1101

1 -All Safari Rack sizes apply to Urban Rack and Urban Rack Black. For part number just replace the "S" with a "U" or "UB" (S5060=U5060=UB5060).

2 -If vehicle is not equipped with a factory roof rack, after-market roof rack, or rain gutters, then roof rails are available.

R3600	(to be used with 50" long Safari Rack).....	36" mount roof rails
R5300	(to be used with 60" long Safari Rack).....	53" mount roof rails
R6200	(to be used with 72", 84" long Safari Rack).....	62" mount roof rails

3 -If using an existing Yakima or Thule rack use our special adapters to attach Safari Rack to their crossbars.

Yakima Adapter- Y400 Thule Adapter- T400

4 -When ordering racks larger than 50" x 60" extra adapters are needed:

S5072- 2 sets (8 adapter pieces)	S5084- 2 sets (8 adapter pieces)
S6572- 2 sets (8 adapter pieces)	S65100- 2.5 sets (10 adapter pieces)
S8072- 2 sets (8 adapter pieces)	S80100- 2.5 sets (10 adapter pieces)

5 - Floor kits add extra floor slats to existing Safari Racks to solidify the floor of the rack.

6 - All full size vans need longer crossbars; please mark part number with a "v" at the end (S5060v).

SAFARI & URBAN RACK APPLICATION GUIDE

VEHICLE	YEAR	SAFARI RACK PART # ¹	RACK SIZE	CROSSBAR	FLOOR KIT PART # ⁵	ADAPTER ²
---------	------	---------------------------------	-----------	----------	-------------------------------	----------------------

LAND ROVER						
DEFENDER- HARD TOP	1993-1997	S5060	50" x 60"	53"	1112	DGM100
DISCOVERY	1994-2004	S4560	45" x 60"	48"	1112	DGM100
DISCOVERY- II	1999-2002	S5060	50" x 60"	53"	1112	DGM100
FREELANDER	2002-2005	S4550	45" x 50"	48"	1110	1101
LR2	2007-2009	S4050	40" x 50"	43"	1109	R3600/CH100
LR3	2005-2009	S4560	45" x 60"	48"	1112	CH100
RANGE ROVER	1986-1995	S5060	50" x 60"	53"	1112	GM100
RANGE ROVER	1996-2009	S5060	50" x 60"	53"	1112	R5300/CH100
RANGE ROVER- Sport	2006-2009	S4550	45" x 50"	48"	1110	R5300/CH100
LEXUS						
GX	2003-2009	S4560	45" x 60"	48"	1112	1101
LX	1996-2009	S5060	50" x 60"	53"	1112	1101
RX	1999-2003	S4550	45" x 50"	48"	1110	CH100
RX	2004-2009	S4550	45" x 50"	48"	1110	1101
LINCOLN						
AVIATOR	2003-2005	S4560	45" x 60"	48"	1112	1101
MARK LT	2006-2007	S5050	50" x 50"	53"	1110	R3600/CH100
MKX	2007-2008	S4550	45" x 50"	48"	1110	R5300/CH100
NAVIGATOR	1998-2006	S5072 ⁴	50" x 72"	53"	1113	1101
NAVIGATOR	2007-2009	S5072	50" x 72"	53"	1113	ER100
NAVIGATOR L	2007-2008	S5084 ⁴	50" x 84"	53"	1114	ER100
MAZDA						
A3	2007-2008	S4050	40" x 50"	43"	1109	R3600/CH100
A5	2007-2008	S4550	45" x 50"	48"	1110	R3600/CH100
CX-7	2008-2009	S4550	45" x 50"	48"	1110	R3600/CH100
CX-9	2007	S4550	45" x 50"	48"	1110	R3600/CH100
CX-9	2008-2009	S5050	50" x 50"	53"	1111	1101
MAZDASPEED3	2008-2009	S4050	40" x 50"	43"	1109	R3600/CH100
MPV	1989-2006	S4560	45" x 60"	48"	1112	1101
TRIBUTE	2001-2009	S4550	45" x 50"	48"	1110	1101
MERCEDES-BENZ						
C-CLASS	2002-2005	S4050	40" x 50"	43"	1109	1101
E-CLASS	1994-2006	S4050	40" x 50"	43"	1109	1101

- 1 -All Safari Rack sizes apply to Urban Rack and Urban Rack Black. For part number just replace the "S" with a "U" or "UB" (S5060=U5060=UB5060).
- 2 -If vehicle is not equipped with a factory roof rack, after-market roof rack, or rain gutters, then roof rails are available.
- | | | |
|-------|--|----------------------|
| R3600 | (to be used with 50" long Safari Rack)..... | 36" mount roof rails |
| R5300 | (to be used with 60" long Safari Rack)..... | 53" mount roof rails |
| R6200 | (to be used with 72", 84" long Safari Rack)..... | 62" mount roof rails |
- 3 -If using an existing Yakima or Thule rack use our special adapters to attach Safari Rack to their crossbars.
- | | |
|----------------------|---------------------|
| Yakima Adapter- Y400 | Thule Adapter- T400 |
|----------------------|---------------------|
- 4 -When ordering racks larger then 50" x 60" extra adapters are needed:
- | | |
|----------------------------------|--------------------------------------|
| S5072- 2 sets (8 adapter pieces) | S5084- 2 sets (8 adapter pieces) |
| S6572- 2 sets (8 adapter pieces) | S65100- 2.5 sets (10 adapter pieces) |
| S8072- 2 sets (8 adapter pieces) | S80100- 2.5 sets (10 adapter pieces) |
- 5 - Floor kits add extra floor slats to existing Safari Racks to solidify the floor of the rack.
- 6 - All full size vans need longer crossbars; please mark part number with a "v" at the end (S5060v).

SAFARI & URBAN RACK APPLICATION GUIDE

VEHICLE	YEAR	SAFARI RACK PART # ¹	RACK SIZE	CROSSBAR	FLOOR KIT PART # ⁵	ADAPTER ²
---------	------	---------------------------------	-----------	----------	-------------------------------	----------------------

OLDSMOBILE						
BRAVADA	1991-2002	S4550	45" x 50"	48"	1110	1101
BRAVADA	2003-2005	S4550	45" x 50"	48"	1110	CH100
SILHOUTTE	1990-2004	S4560	45" x 60"	48"	1112	1101
PONTIAC						
AZTEK	2001-2005	S5050	50" x 50"	53"	1110	CH100
MONTANA	1999-2005	S4560	45" x 60"	48"	1112	1101
TORRENT	2006	S4550	45" x 50"	48"	1110	CH100
TORRENT	2007-2008	S4550	45" x 50"	48"	1110	R3600/CH100
VIBE	2003-2008	S4050	40" x 50"	43"	1109	ER100
PORSCHE						
CAYENNE	2003-2009	S4560	45" x 60"	48"	1112	CH100
SAAB						
9-3 SPORT COMBI	2007-2009	S4050	40" x 50"	43"	1109	1101
9-5 SPORT COMBI	2007-2009	S4050	40" x 50"	43"	1109	1101
9-7X	2005-2009	S4550	45" x 50"	48"	1110	1101
SATURN						
OUTLOOK	2007-2009	S4060	40" x 60"	43"	1111	ER100
RELAY	2007	S4560	45" x 60"	48"	1112	1101
VUE	2002-2009	S4550	45" x 50"	48"	1110	1101
SUBARU						
BAJA	2003-2006	S4550	45" x 50"	48"	1110	1101
BAJA	2007	N/A	N/A	N/A	N/A	N/A
FORESTER	1998-2009	S4060	40" x 60"	43"	1111	1101
LEGACY	1990-2007	S4060	40" x 60"	43"	1111	1101
OUTBACK	1996-2009	S4050	40" x 50"	43"	1109	1101
OUTBACK SPORT	1996-2007	S4050	40" x 50"	43"	1109	1101
TRIBECA	2007-2008	S4560	45" x 60"	48"	1112	1101
TRIBECA	2009	S4560	45" x 60"	48"	1112	R5300/CH100
WRX	2007-2008	S4050	40" x 50"	43"	1109	1101
SUZUKI						
FORENZA (Wagon)	2005-2008	S4550	45" x 50"	48"	1110	1101
GRAND VITARA	1999-2006	S4550	45" x 50"	48"	1110	1101
GRAND VITARA	2007-2008	S4050	40" x 50"	43"	1109	ER100
RENO	2007-2008	S4050	40" x 50"	43"	1109	R3600/CH100

1 -All Safari Rack sizes apply to Urban Rack and Urban Rack Black. For part number just replace the "S" with a "U" or "UB" (S5060=U5060=UB5060).

2 -If vehicle is not equipped with a factory roof rack, after-market roof rack, or rain gutters, then roof rails are available.

R3600	(to be used with 50" long Safari Rack).....	36" mount roof rails
R5300	(to be used with 60" long Safari Rack).....	53" mount roof rails
R6200	(to be used with 72", 84" long Safari Rack).....	62" mount roof rails

3 -If using an existing Yakima or Thule rack use our special adapters to attach Safari Rack to their crossbars.

Yakima Adapter- Y400 Thule Adapter- T400

4 -When ordering racks larger than 50" x 60" extra adapters are needed:

S5072- 2 sets (8 adapter pieces)	S5084- 2 sets (8 adapter pieces)
S6572- 2 sets (8 adapter pieces)	S65100- 2.5 sets (10 adapter pieces)
S8072- 2 sets (8 adapter pieces)	S80100- 2.5 sets (10 adapter pieces)

5 - Floor kits add extra floor slats to existing Safari Racks to solidify the floor of the rack.

6 - All full size vans need longer crossbars; please mark part number with a "v" at the end (S5060v).

SAFARI & URBAN RACK APPLICATION GUIDE

VEHICLE	YEAR	SAFARI RACK PART # ¹	RACK SIZE	CROSSBAR	FLOOR KIT PART # ⁵	ADAPTER ²
---------	------	---------------------------------	-----------	----------	-------------------------------	----------------------

SUZUKI continued

SIDEKICK 4 DR	1989-1998	S4050	40" x 50"	43"	1109	1101
SX4	2007-2009	S4550	45" x 50"	48"	1110	1101
VITARA	1999-2005	S4050	40" x 50"	43"	1109	V100
XL-7	2001-2006	S4560	45" x 60"	48"	1112	1101
XL-7	2007-2009	S4560	45" x 60"	48"	1112	ER100

TOYOTA

4-RUNNER	1996-2002	S4560	45" x 60"	48"	1112	CH100
4-RUNNER	2003-2009	S4560	45" x 60"	48"	1112	1101
HIGHLANDER	2001-2009	S4550	45" x 50"	48"	1110	1101
LANDCRUISER	1986-2009	S5060	50" x 60"	53"	1112	1101
W/OUT RACK	1986-1997	S5060	50" x 60"	53"	1112	GM100
RAV-4 4 DR	1996-2000	S4050	40" x 50"	43"	1109	RAV100
RAV-4 4 DR	2001-2009	S4550	45" x 50"	48"	1110	1101
SEQUOIA	2001-2009	S5072 ⁴	50" x 72"	53"	1113	1101
SIENNA	1998-2009	S4560	45" x 60"	48"	1112	1101
TACOMA	1995-2009	S4550	45" x 50"	48"	1110	R3600/CH100
TUNDRA	2000-2009	S5050	50" x 50"	53"	1110	R3600/CH100

VOLKSWAGON

EUROVAN	1999-2003	S5084	50" x 84"	53"	1114	R6200/CH100
PASSAT WAGON	2007-2009	S4050	40" x 50"	43"	1109	1101
ROUTAN	2009	S5060	50" x 60"	53"	1112	1101
TIGUAN	2008-2009	S4550	45" x 50"	48"	1110	1101
TOUAREG	2004-2006	S4560	45" x 60"	48"	1112	CH100
TOUAREG	2007-2009	S4560	45" x 60"	48"	1112	1101

VOLVO

CROSS COUNTRY	1998-2006	S4560	45" x 60"	48"	1112	1101
V50	2005-2008	S4050	40" x 50"	43"	1109	1101
V70	1998-2008	S4550	45" x 50"	48"	1110	1101
XC60	2009	S4550	45" x 50"	48"	1110	R5300/CH100
XC70	2003-2009	S4550	45" x 50"	48"	1110	1101
XC90	2003-2009	S4560	45" x 60"	48"	1112	1101

- 1 -All Safari Rack sizes apply to Urban Rack and Urban Rack Black. For part number just replace the "S" with a "U" or "UB" (S5060=U5060=UB5060).
- 2 -If vehicle is not equipped with a factory roof rack, after-market roof rack, or rain gutters, then roof rails are available.
- | | | |
|-------|--|----------------------|
| R3600 | (to be used with 50" long Safari Rack)..... | 36" mount roof rails |
| R5300 | (to be used with 60" long Safari Rack)..... | 53" mount roof rails |
| R6200 | (to be used with 72", 84" long Safari Rack)..... | 62" mount roof rails |
- 3 -If using an existing Yakima or Thule rack use our special adapters to attach Safari Rack to their crossbars.
- | | |
|----------------------|---------------------|
| Yakima Adapter- Y400 | Thule Adapter- T400 |
|----------------------|---------------------|
- 4 -When ordering racks larger than 50" x 60" extra adapters are needed:
- | | |
|----------------------------------|--------------------------------------|
| S5072- 2 sets (8 adapter pieces) | S5084- 2 sets (8 adapter pieces) |
| S6572- 2 sets (8 adapter pieces) | S65100- 2.5 sets (10 adapter pieces) |
| S8072- 2 sets (8 adapter pieces) | S80100- 2.5 sets (10 adapter pieces) |
- 5 - Floor kits add extra floor slats to existing Safari Racks to solidify the floor of the rack.
- 6 - All full size vans need longer crossbars; please mark part number with a "v" at the end (S5060v).